



What's in the Box?



Model SS1

- 1 - **Swaba Model SS1** - Unit & Fill Plug
- 2 - **Adapter Set:** Fits most popular sinks
- 3 - **Adapter** tightening tool
- 4 - **Rubber** adapter gaskets
- 5 - **Plumbers tape**, just in case

Safety Precautions

1. **Do not drink** the soap, or bubbly water.
2. **Only use CLEAR dish soap** in Swaba. NO Particles. Other soaps can clog and not work as well.
3. **To avoid injury:** Mild - Warm water is always best. DO NOT USE Scalding water.
4. **Do not** take unit apart or dismantle in any way.

Trouble Shooting

1. **Leaky at faucet:** Tighten adapter, or install rubber gasket before installing adapter.
2. **No stream of water:** Water outlet may be clogged.
3. **No suds or bubbles:** Reservoir is empty or clogged. Fill reservoir with dish soap and run warm water through it until bubbles are constant.


Technical Specifications

1. **Reservoir size:** 3 ounces
2. **Adapter sizes:** Fits 22 and 24 mm threaded faucets



Phone: 650-649-8176
tfc423@pacbell.net
www.swabaproducts.com
PO Box 620824
Woodside, CA 94062

Find
Out
More



Designed in USA . Made in China



Model SS1

Fits most popular faucet brands



Installation is EASY. Just follow these Simple Installation Steps and you're done in minutes.



❶ Select the correct size adapter to fit your faucet thread.

First check if you have an **inside or outside** thread. Then select the right size. Only one will fit properly.



Remove existing faucet aerator. You may need a small channel lock / pliers for this. Wrap aerator with rag so it does not scuff.



Place Swaba mounting ring over end of faucet - slide back out of the way for now. Open thread end facing down.



Insert rubber gasket into faucet adapter. Using the right size gasket, drop into end and then push evenly around edges so it fits flat.



Twist on correct adapter to end of faucet. Start slow to be sure threads fit properly. When finger tight - use tightening tool to set snug.



Attach Swaba Unit: Hold and press unit up on to adapter until seated evenly. Then bring adapter ring down and tighten on to base.



Fill with Liquid Dish Soap. Remove Fill Cap and fill soap reservoir until full. Push Fill Cap back into place when done.



Model SS1

Operating Instructions: Model SS1

- Fill reservoir with liquid dish soap
- Turn on water to **Slow or Medium**.
- Turn "Select Handle" to desired position of Suds or Spray
- Turn faucet water OFF when done.
- Refill soap reservoir when needed.

Soap Suds



Suds Stream



Water Spray

